



High-Speed Passenger Elevator Planning Guide

The information in this catalogue is subject to change without notice. The information and diagram in this catalogue reflect the technical feature and configuration of the elevator model at press time (refer to the version number). In line with the principle of continuous development of products, our company reserves the right to change the selection of product technical parameters and colour at any time. The existing image technology cannot accurately reproduce the elevator component structure and decoration colour. Therefore, this catalogue only provides general information, not as a contract document. The specific configuration parameters are subject to the formal agreement.

If you need detailed information, please contact us.

# **Elevator Specification List**


02	Specification
03	Layout
04	FI System
07	Elevator Function
09	Overhead Height and Pit Depth
10	Hoistway and Machine Room
15	Entrance Design
17	Electrical Information
18	Electrical Data
19	Civil Works Matters

Load (kg)	No. of Passengers ①	Speed (m/min)	Maximum Number of Stops	Maximum Travel (m)	Maximum Travel with Fireman Operation (m)	Minimum Floor Height (mm)
900	12	300/360		250	250	
1050	14	300/360		250	250	
1150	15	300/360		250	250	
1350	18	300/360	64 (Duplex / Group Control)	250	250	2800
1600	21	300/360	80 (Simplex Control)	220	220	2800
1800	24	300/360		200	200	
2000	26	300/360		250	250	
2250	30	300/360		200	200	

Load (kg)	No. of Passengers ①	Speed (m/min)	Maximum Number of Stops	Maximum Travel (m)	Maximum Travel with Fireman Operation (m)	Minimum Floor Height (mm)
1150	15	420/480		285	285	
1350	18	420/480	64 (Duplex / Group Control)	285	285	2800
1600	21	420/480	80 (Simplex Control)	285	285	2800
1800	24	420/480		285	285	


- Note:
  ① Passenger numbers calculated at 75kg per person.
  ② The information above are based on GB standards.
  ③ The maximum travel for the load of 1150/1350/1600kg with speed of 300/360 m/min could be up to 330m with conditions. Details, please contact us.
  ④ The maximum travel for the load of 1800kg with speed of 300/360 m/min could be up to 300m with conditions. Details, please contact us.


## FI System



- Maximum in-line arrangement is 4 elevators.
- Elevators in different groups should not be set in the same line.
- Avoid placing the elevators entrance near pillars.

- More than 5 units in the same group, the elevators should be set face-to-face.
   And the distance of facing elevators(L) should be 3.5~4.5m.
- Different group elevators with face-to-face arrangement, the distance of facing elevators(L) should be more than 6m.





- Elevators in same group should have same stops.
- Elevators in same group should be set the same floor as basement and not recommend to set several entrance.

#### <FI-600 Features> Future Reference-Trajectory Control

A group control system groups multiple elevators for achieving a well-balanced operation by taking waiting times into account. Such a system requires flexibility so that it can be used in various types and sizes of buildings and be responsive to changing traffic demand.

(FI-600)	(FI-100)	(FI-10)
(3-8 Cars)	(3-6 Cars)	(3-4 Cars)
Allows a flexible control for elevator car allocation and the required number of cars according to the congestion state in the building and the type of building.	Elevator cars are allocated at equal time intervals according to "Reference-Trajectory Control" for shortening the average waiting times and reducing the probability of a long wait.	Provides a ring control to allocate the elevator car closest to the floor where a new hall call is registered.

	Instantaneous reservation and service forecasting			
	Intelligent function			
	Generation of new traffic flow modes Generation of optimum operation programs			
	Congested floor recognition			
Basic	Learning	function		
Specification		Collection of usage data     Recognition of traffic flow mode (40/2 modes)     Search for optimum operation program		
	Arrival notice indication			
	Bunching p			
	Future reference-trajectory control	Reference-trajectory control	Ring control	
	Forecasting dynamic allocation control	Zone distribution control	Fixed floor distribution control	
System name	FI-600	FI-100	FI-10	
Recommended number of cars in a group	3~8 cars	3~6 cars	3~4 cars	
Type of building	Large office buildings and hotels	Small office building, department stores, hotels and hospitals	Building with small traffic demand	
	V	n		
Optional	Service floo	or selection		
	Destination floor reservation system Centralized control for special floors Zoning express service			

#### Note:

① Bunching prevention: Using the "future reference-trajectory control" or the "reference-trajectory control" in the FI-600 or FI-100, elevator cars are operated at equal time intervals to prevent local bunching.

# FI System

## Basic Function ● : Basic spec. - : Not applicable

No.		Item	Content	FI-600	FI-100	FI-10
1		neous reservation rvice forecasting (FI-IRF)	Upon receipt of a hall call, this function activates and elevator to serve this call, and at the same time the call is acknowledged by the hall lantern and chime.	•		
2	Arrival notice indication (FI-ANI)		Four to five seconds prior to the arrival of an elevator, this function will activate the hall lantern flickering and the chime sound.	•	•	<b>A</b>
	Basic call	Future reference- trajectory control (FI-FRTC)	Controls the allocation of elevator cars to hall calls according to the future reference trajectory resulting from learning-based daily traffic flows.	•		
3	assignment control	Reference- trajectory control (FI-RTC)	Controls the allocation of elevator cars to hall calls based on the theory used in the highest model in the FI series, FI-600, and the intelligent-based data containing our know-how accumulated over a long period of time.		•	
	Perso	nalized control	Through the hall call assignment control of waiting time priority assignment, constantly carry out operation management in accordance with waiting time priority.	•	•	
4	Waiting time	e priority assignment	Prevent long waiting time of passengers by implementation of hall call assignment.	•	•	
	Riding time	priority assignment	Prevent long riding time of passengers by implementation of hall call assignment.	<b>A</b>	<b>A</b>	
	Bunching	prevention (FI-BP)	This function prevents local bunching of elevator cars using the "future reference-trajectory control" or the "reference-trajectory control" for operating cars at equal time intervals.	•	•	
		Collection of usage data (FI-CUD)	Collects the traffic status information by floor and direction for a unit time based on the elevator information such as car positions and the number of passengers getting on and off, and hall call information.	•	•	
5	Learning function	Recognition of traffic flow mode (FI-RTM)	Extracts characteristics at any given moment, including congested floors, from the collected usage data, and identifies the traffic flow mode at that moment.	(40 modes)	(2 modes)	
		Search for optimum operation program (FI-SOP)	Searches the optimum operation program of the moment based on the identified traffic mode.	•	•	
6		ed floor recognition (FI-CFR)	Identifies congested floors according to the usage data learned in each traffic flow mode.	•		
7	a	ecasting for hall call ssignment (FI-SFH)	This function assigns elevator cars to hall calls more precisely by forecasting the arrival time and number of passengers in the car according to the learning-based traffic demand.	•		
	Intelligent	Generation of new traffic flow modes (FI-GNT)	Extracts new characteristics according to the learning-based usage data, and registers them as a building-specific new traffic flow mode.	•		
8	function Generation of optimum operation programs (FI-GOP)		Generates an optimum operation program for a building by simulating the elevator operation according to the usage data learned in each traffic mode and preferential control target.	•		
9	Energy saving preference control (FI-ESC)		This system reduces the number of elevator cars in service when traffic demand is low.	•		
	Floor	Forecasting dynamic allocation control (FI-FDA)	Dynamically allocates elevator cars in response to continuously changing situation in the building by determining the area assigned to each car according to the forecasted number of passengers and car usage.	•		
10	standby	Zone distribution control (FI-ZD)	Distributes the waiting elevator cars to the pre-assigned zones.	_	•	_
		Fixed floor distribution (FI-FD)	Distributes the waiting elevator cars to the pre-assigned floors.	_		•

#### **Basic Function**

<ul><li>Basic spec.</li></ul>	▲ : Option spec.	— : Not applicab

No.	Item	Content	FI-600	FI-100	FI-10
11	Learning based concentrated service (FL-LCS)	Centralizes the service to the learning-based congested floors during peak times including morning, lunch time and evening peaks while taking the service for other floors into account.	•		
12	Rush-hour schedule operation	All the elevators will automatically return to the start floor after serving the last call during this preset rush-hour timing.	•		<b>A</b>
 13	Destination floor priority control	The allocation will be priority when the destination floor and the hall call is the same floor.	•	•	
14	Full car forecasting control	Control the new allocation according to the number of passengers in car and the times of new calls.	•	•	
15	Full car control	Stop new allocation or re-allocate the car when full load.	•	•	
16	Long waiting time allocation control	Re-allocate the cars when long waiting time situation is forcasted.	•	•	
17	Notice function	Keep the service elevator car door open with hall lantern flickering to guide the passengers.	<b>A</b>	•	
18	Automatic door open time control (FI-ADT)	This function automatically controls the duration of the door open time according to the floor and the kind of call (hall call or car call) as well as the elevator condition.	•	•	

## Operating Function

No.	Item	Content	FI-600	FI-100	FI-10
1	Centralized control for special floors (FI-CCF)	This function preferentially assigns an elevator to the special floor. (e.g. the director's room)	<b>A</b>		
2	Service floor selection (FI-SFS) [Floor lock-out operation]	Allows the operator to select the service and non-service floors using, for example, the switches on the control panel.	<b>A</b>	<b>A</b>	
3	VIP service (FI-VIP)	When welcoming or sending off important guest, this function permits an elevator to be summoned directly to the desired car call floor by pushing a specially provided switch.	•	<b>A</b>	<b>A</b>
4	DFRS	Each passenger registers their destination floor on the registration device located at the landing hall and know in advance the designated elevator to take. System assigned one elevator for the passengers with the same destination floor. This helps to reduce congestion in the elevator lobby and improve efficiency.			_
5	Zoning express service (FI-EZS)	Start a divided express service when the peak traffic demand takes place in the present time zones.	<b>A</b>		

### Man-machine Function

No.	Item	Content	FI-600	FI-100	FI-10
1	Malicious operation cancelled function	Cancel the allocation when system identifies the call is malicious.	•	•	
2	Hall information (FI-HI)	General and elevator operation information is indicated on the LED or LCD hall indicator.			•

# **Elevator Function**

# **Elevator Function**

#### Standard Function

O tarraar t			
Control S	ystem		
SA1	Simplex Collective Control	SA2	Floor Height Self Measurement
SA3	On-Cage (Car Top) Maintenance Operation	SA4	In-Cage Slow Speed Operation
SA5	Machine-Room Debugging Operation Function		
System F	Protection		
SB1	Over Speed Electrical Protection	SB2	Overspeed Mechanical Protection
SB3	Rope Slipping Running Protection	SB4	Motor Overload (Thermal) Protection
SB5	Automatic Fault Detection	SB6	Automatic Fault Recording
SB7	Standby Regular Auto-Check	SB8	Double Brake-Safety Check Operation
SB9	Synchronous Motor Magnetic Pole Static Test	SB10	Lift-Position Abnormily Auto-Correction Function
SB11	Nearest Landing Operation	SB12	Anti-electromagnetic Interference
Safe Con	nmunication		
SC1	Interphone System (5 Ways)		
Safe Ridi	ng		
SD1	Out of Door-Open Zone Alarm	SD2	Alarm System
SD3	Door Safety Return System	SD4	Full Load Bypass Operation
SD5	Overload Detection System	SD6	Overload Alarm
SD7	Next Drive (Door Open Abnormity)	SD8	Door Opening / Closing Time Abnormity Protection
SD9	Automatic Door Dwell Time Control	SD10	Automatic Door Dwell Time Adjustment
SD11	Number of Runs Indicator	SD12	Multi-Beam Protection ①
SD13	Inspection Indication in Hall Indicator	SD14	Current Floor Push-Button Reopening Function ①
SD15	Overload Indicator (In Car)	SD16	Emergency Terminal Stopping Device, ETSD
Emergen	cy Solution		
SE1	Car Emergency Lighting	SE2	Fire Emergency Operation (Automatic)
Design fo	or Comfort		
SF1	Parking Operation	SF2	Automatic Return Function
SF3	Start Torque Auto-Adjustment	SF4	Door-Stop Function (Maintenance)
SF5	Micro Levelling (Travel ≥45m)	SF6	Advance Door Opening
SF7	Mischievous Call Cancellation	SF8	Opposite Direction Car Call Cancellation
SF9	Car Light Auto Turn-off	SF10	Car Fan Auto Turn-off
SF11	Abnormal Duration Hall Call Detection ① (Applicable for Simplex, Duplex and FI-10 only.)	SF12	Car Floor Button Flashing ①
SF13	Car Call Deselect Function	SF14	Regenerative System Function
SF15	Door Bypass Detection	SF16	Overload Hall Call Recovery Function (Not applicable for FI-100 and FI-600.)
SF17	Base Floor Selection (Applicable for Simplex only.)		

### Optional Function

Control S	System		
OA1	Simplex Down Collective Control	OA2	Duplex Collective Control
OA3	Duplex Down Collective Control	OA4	FI-10 ①
OA5	FI-100 ①	OA6	FI-600 ①
OA7	Independent Automatic Operation ①	OA8	VIP Service
OA9	Rush Hour Schedule Operation (Not applicable for FI-100)		
Safe Cor	mmunication		
OB1	Contact at Control Panel (RS485)	OB2	Elevator Monitoring System (Computer Type)
OB3	Supervisory Panel (Dry Contact Type)	OB4	Twisted Pair Cable (1 pair) for CCTV
OB5	Twisted Pair Cable (1 pair) for BGM Interface	OB6	Contact at Control Panel (Dry Contact)
OB7	Camera Device in Inside the Car		
Safe Rid	ing		
OC1	Multi-Beam + Safety Edge Protection	OC2	Card Reader Interface (In Car) (RS485) ① (Not applicable when OE5 is selected.)
Emergen	ncy Solution		
OD1	Fireman Operation (Load≥825kg)	OD2	Automatic Rescue Device (ARD) (Maximum travel distance ≤ 30m)
OD3	EM. Operation for Power Failure (Manual)	OD4	EM. Operation for Power Failure (Auto)
OD5	Earthquake Emergency Operation	OD6	Pit Flood Operation
Design fo	or Comfort		
OE1	Attendant Operation	OE2	Independent Operation
OE3	Voice Synthesizer	OE4	Arrival Chime (Car Top and Bottom)
OE5	Floor Lock Out Operation ① (Not applicable when OC2 is selected.)	OE6	Door Opening Prolong Button
OE7	Hall Call Registration in Car Operating Panel (Applicable when OE1 is selected)	OE8	Sub Car Operating Panel
OE9	Double Opening Function ① (Not applicable for FI-100, FI-600 and FI-10 (>48 stops.)	OE10	Horizontal Car Operating Panel
OE11	Braille Button	OE12	EMC ①
OE13	Operation Status Indication at Hall Indicator	OE14	DFRS (Under FI-600)
OE15	Hall Call Deselect Function ① (Applicable for Simplex, Duplex and FI-10 only.)		

① Details, please contact us.

Note:
1 Details, please contact us.


## Overhead Height and Pit Depth

# Hoistway and Machine Room (Standard Car Design, Counterweight Location: Rear)


Load (kg)	Speed (m/min)		Height OH nm)		epth P im)
(Ng)	(11//11111)	Double	Single	Double	Single
900	300	7100	6900	3750	4100
900	360	7400	7100	4100	4400
1050	300	7100	6900	3750	4100
1030	360	7400	7100	4100	4400
	300	7100	6900	3750	4100
1150	360	7400	7100	4100	4400
1150	420	7900		5850	
	480	8100		5850	
	300	7100	6900	3750	4100
1350	360	7400	7100	4100	4400
1350	420	7900		5850	
	480	8100		5850	
	300	7100	6900	3750	4100
1600	360	7400	7100	4100	4400
1600	420	7900		5850	
	480	8100	_	5850	
	300	7100	6900	3750	4100
1800	360	7400	7100	4100	4400
1800	420	7900		5850	
	480	8100		5850	
2000	300	7100	6900	3750	4100
2000	360	7400	7100	4100	4400
0050	300	7100	6900	3750	4100
2250	360	7400	7100	4100	4400

#### Note:


- $\ensuremath{\mathfrak{D}}$  The information and dimensions above are based on GB standards.
- $\ensuremath{\textcircled{2}}\xspace \ensuremath{\textcircled{Configuration}}\xspace is based on rear counterweight arrangement without counterweight safety gear.$
- $\begin{tabular}{l} \end{tabular}$  The information above is based on decoration weight provision up to 450kg.
- 4 The overhead height above is based on bare ceiling height of 2800mm.
- The pit depth above is based on standard vinyl tile finish without floor recess.



## Machine-room Plan (Not applicable for speed 420 & 480m/min)



## Hoistway Plan (Not applicable for speed 420 & 480m/min)




#### Note:

- ① Items with "\*" shall be furnished by building contractors.
- Hoistway shall not be located next to bedrooms, classroom, ward, library or any other places where low poice is required.
- or any other places where low noise is required.


  ③ The hoistway construction shall be reinforced concrete ring beam with strength C25 or whole hoistway of reinforced concrete wall. If you have other situations, please contact us.
- 4 For hoistway and machine room details, please contact us.
- 5 Unit of dimension shall be in mm unless otherwise stated.

# Hoistway and Machine Room (Standard Car Design, Counterweight Location: Rear)

#### Machine-room Plan



#### Hoistway Plan



#### Note:

- ① Items with "\*" shall be furnished by building contractors.
- Hoistway shall not be located next to bedrooms, classroom, ward, library or any other places where low noise is required.
- ③ The hoistway construction shall be reinforced concrete ring beam with strength C25 or whole hoistway of reinforced concrete wall. If you have other situations, please contact us.
- $\ensuremath{\mathfrak{A}}$  For hoistway and machine room details, please contact us.
- ⑤ Unit of dimension shall be in mm unless otherwise stated.

#### Single

Load	Speed		Size ım)		Opening nm)	Arrang	t Wall gement m)	Hoistway (mm)	Machine Room (mm)		R	eactior (K	ı Loadi N)	ng	
(kg)	(m/min)	Internal	External	Туре	Width	L1	L2	X×Y	S×T	Mac Ro	hine om		Р	it	
		(a×b)	(A×B)		(OP)			Single	Single	R1	R2	R3	R4	R5	R6
900	300	40004050	47004570	20.00	000	F70	F70	22402250	25704050	265	165	520	520	160	160
900	360	1600×1350	1700×1570	2P-CO	900	570	570	2240×2350	2570×4050	265	165	580	580	160	160
1050	300	40004500	47004700	00.00	000	570	F70	00400500	05704000	265	165	520	520	160	160
1050	360	1600×1500	1700×1720	2P-CO	900	570	570	2240×2500	2570×4200	265	165	580	580	160	160
1150	300	40004500	40004700	00.00	4000	000	000	0.4.400500	00704000	290	195	550	550	180	180
1150	360	1800×1500	1900×1720	2P-CO	1000	620	620	2440×2500	2670×4200	290	195	600	600	180	180
1350	300	2000-4500	240044720	20.00	4400	670	670	2040+2500	2770,4200	310	200	560	560	185	185
1330	360	2000×1500	2100×1720	2P-CO	1100	670	670	2640×2500	2770×4200	310	200	610	610	185	185
1600	300	00004700	04004000	20.00	4400	070	670	00400700	07704400	310	215	580	580	190	190
1600	360	2000×1700	2100×1920	2P-CO	1100	670	670	2640×2700	2770×4400	310	215	630	630	190	190
1800	300	00004700	00004000	00.00	4000	700	700	00400700	00404400	325	230	600	600	195	195
1800	360	2200×1700	2300×1920	2P-CO	1200	720	720	2840×2700	2940×4400	325	230	650	650	195	195
2000	300	00004050	00000070	00.00	4000	700	700	00400050	20404550	325	230	610	610	195	195
2000	360	2200×1850	2300×2070	2P-CO	1200	720	720	2840×2850	2940×4550	325	230	670	670	195	195
2250	300	22002000	22002220	20.00	4000	700	700	2040-2000	2040::4700	325	230	610	610	195	195
2230	360	2200×2000	2300×2220	2P-CO	1200	720	720	2840×3000	2940×4700	325	230	670	670	195	195

#### Double


Load	Speed		Size im)		Opening nm)	Arrang	t Wall gement im)	Hoistway (mm)	Machine Room (mm)		R	eactior (K	ı Loadi N)	ng	
(kg)	(m/min)	Internal	External	Туре	Width	L1	L2	X×Y	S×T		hine om		Р	it	
		(a×b)	(A×B)		(OP)			Double	Double	R1	R2	R3	R4	R5	R6
1150	300	40004500	40004700	20.00	4000	000	000	40500400	50504400	290	195	550	550	180	180
1150	360	1800×1500	1900×1720	2P-CO	1000	600	600	4950×2480	5050×4180	290	195	600	600	180	180
1350	300	00004500	04004700	00.00	4400	050	050	F0F00400	F450::4400	310	200	560	560	185	185
1330	360	2000×1500	2100×1720	2P-CO	1100	650	650	5350×2480	5450×4180	310	200	610	610	185	185
4000	300	00004700	04004000	00.00	4400	050	050	50500000	F.4504000	310	215	580	580	190	190
1600	360	2000×1700	2100×1920	2P-CO	1100	650	650	5350×2680	5450×4380	310	215	630	630	190	190
4000	300	0000 4700	0000 4000	00.00	4000	700	700	F750 0000	5050 4000	325	230	600	600	195	195
1800	360	2200×1700	2300×1920	2P-CO	1200	700	700	5750×2680	5850×4380	325	230	650	650	195	195
2000	300	00001050	00000070	00.00	4000	700	700	F7F00000	50504500	325	230	610	610	195	195
2000	360	2200×1850	2300×2070	2P-CO	1200	700	700	5750×2830	5850×4530	325	230	670	670	195	195
2250	300	00000000	00000000	00.00	4000	700	700	F7F00000	50504000	325	230	610	610	195	195
2250	360	2200×2000	2300×2220	2P-CO	1200	700	700	5750×2980	5850×4680	325	230	670	670	195	195

#### Note:


- $\ensuremath{\textcircled{1}}$  The information and dimensions above are based on GB standards.
- $\ensuremath{\textcircled{2}}$  Hoistway dimension for double elevators are based on 150mm width separator beam.
- 3 Configuration is without counterweight safety gear.

# Hoistway and Machine Room (Standard Car Design, Counterweight Location: Rear)

#### Machine-room Plan



#### Hoistway Plan



#### Note

- ① Items with "\*" shall be furnished by building contractors.
- ② Hoistway shall not be located next to bedrooms, classroom, ward, library or any other places where low noise is required.
- ③ The hoistway construction shall be reinforced concrete ring beam with strength C25 or whole hoistway of reinforced concrete wall. If you have other situations, please contact us.
- $\ensuremath{\mathfrak{A}}$  For hoistway and machine room details, please contact us.
- 5 Unit of dimension shall be in mm unless otherwise stated.

#### Double


Load	Speed		Size m)		Opening nm)	Arrang	t Wall gement m)	Hoistway (mm)	Machine Room (mm)		R	eactior (K	i Loadi N)	ng	
(kg)	(m/min)	Internal	External	Туре	Width	L1	L2	X×Y	S×T	Mac Ro	hine om		Р	it	
		(a×b)	(A×B)		(OP)			Double	Double	R1	R2	R3	R4	R5	R6
1150	420	1800×1500	1900×1720	2P-CO	1000	600	600	4950×2480	5050×4910	290	195	600	600	185	185
1130	480	1600×1500	1900×1720	2P-CO	1000	600	600	4950×2460	5050×4910	290	195	720	720	185	185
1350	420	2000×1500	2100×1720	2P-CO	1100	650	650	5350×2480	5450×4910	310	200	610	610	190	190
1330	480	2000*1500	2100×1720	2P-00	1100	650	650	5350×2460	5450×4910	310	200	730	730	190	190
1600	420	2000×1700	2100×1920	2P-CO	1100	650	650	5350×2680	5450×5110	320	215	640	640	195	195
1000	480	2000×1700	2100×1920	2P-CO	1100	650	650	5350*2660	5450×5110	320	215	780	780	195	195
1800	420	2200×1700	2300×1920	2P-CO	1200	700	700	5750×2680	5850×5110	325	230	660	660	200	200
1000	480	2200*1700	2300*1920	2P-00	1200	700	700	5/50*2000	3030×3110	325	230	800	720	200	200

#### Not


- ① The information and dimensions above are based on GB standards.
- 2 Hoistway dimension for double elevators are based on 150mm width separator beam.
- 3 Configuration is without counterweight safety gear.

## **Entrance Design**

#### Elevation of Entrance









For Entrance Without Fireman Switch

## Structure Opening of Entrance ①



For Entrance With Fireman Switch



For Entrance Without Fireman Switch

T	AC 4V	CC 4V
туре	AS-TX	55-17
W	10	25
D	10	25

- ① Structural opening of entrance shall be furnished by building contractor.
- ② Unit of dimension shall be in mm unless otherwise stated.
- 3 Applicable only when fireman operation function with fireman switch is located at lift landing.

## **Entrance Design**


The followings shall be furnished by building contractors:


Building Structure

Grouting Work


Wall and Floor Finishes


## Narrow Jamb (AS-1X)





### Wide Jamb (SS-1X)






16

## **Electrical Information**

The followings shall be furnished by building contractors:

---- Electrical Equipment

— Cable



- ① Main Power Supply: Three-phase, five wires system, AC380V 50Hz ② Lighting Power Supply: Single-phase, three wires system, AC220V 50Hz

Item	Works to be provided by building contractor
Main Power Supply	To provide power supply switch around the entrance of machine room. To install facilities to ensure that power supply voltage fluctuation shall be within ±7%.
Lighting Power Supply	To provide lighting power supply for car lighting, fan and indicator.
Ventilation Device	To provide mechanical ventilation to the machine room to ensure that the temperature in the machine room is maintained at below 40°C.
Pit light, Switch Socket Outlet	To provide single phase AC 220V, 10A switch socket outlet and pit lighting with switch below the entrance floor level for maintenance purposes.

## Electrical Data

No.	Load	Speed	Voltage		Breaker city (A)		former ty (kVA)		Power ze (mm²)		/ire Size m²)	Machine Room Ventilation
INO.	(kg)	(m/min)	vollage	1 unit	2 units	1 unit	2 units	1 unit	2 units	1 unit	2 units	Ventilation Fan Size Dia (Ø mm)
	900	300		200	200	40	80	60	125	30	65	400
1	900	360		200	200	50	100	80	150	40	75	350×2
2	1050	300		200	200	50	80	60	125	30	65	350×2
2	1050	360		200	200	63	100	80	200	40	100	350×2
		300		200	200	50	100	60	125	30	65	350×2
3	1150	360		200	200	63	125	80	200	40	100	400×2
3	1130	420		250	250	63	125	100	280	50	140	400×2
		480		250	250	80	125	125	325	65	165	400×2
		300		200	200	63	100	80	150	40	75	350×2
4	1350	360		200	200	80	125	80	200	40	100	400×2
4	1330	420	3Ф380V	250	250	80	125	100	280	50	140	400×2
		480	1Φ220V	250	250	80	160	125	325	65	165	400×3
		300	50Hz	200	200	63	125	80	150	40	75	400×2
5	1600	360	SUFIZ	200	250	80	160	80	200	40	100	400×2
5	1600	420		250	250	80	160	125	325	65	165	400×3
		480		250	275	100	200	150	350	75	175	400×3
		300		200	250	80	160	100	200	50	100	400×2
6	1800	360		200	250	100	160	125	325	65	165	400×3
6	1000	420		250	275	100	200	125	325	65	165	400×3
		480		250	325	125	200	150	350	75	175	400×3
7	2000	300		200	250	80	160	100	200	50	100	400×2
7	2000	360		225	300	100	200	125	325	65	165	400×3
0	2250	300		225	275	100	160	100	200	50	100	400×3
8	2250	360		225	325	125	200	100	280	50	140	400×3

- ① The main power wire size specified above is applicable for wire length less than 150m. For main power wire length more than 150m, please calculate using the following formula: Main power wire size(mm2) = [Actual wire length / 150] × [Wire size in above table]
- 2 Ventilation rate of fan shall be as below:

Fan Size (Φmm)	Ventilation Rate (m³/h)
350	2460
400	3720

## Note

#### Working environment of the elevator shall be as follow:

- 1. Ambient temperature shall be between 5°C to 40°C.
- 2. Maximum relative humidity is 90%, and the monthly mean minimum temperature should be below 25°C.
- 3. Supply voltage fluctuation shall be within ±7°C.
- 4. Surrounding environment shall be free from explosive & corrosive hazard, anti-insulation and conductive particles atmosphere.

#### About hoistway and machine-room:

1. Hoistway walls (including reinforced concrete ring beams) should be vertical, and the allowable deviation for the hoistway verticality is:

Total Height ≤ 30m:0~+25mm.

30m<Total Height ≤ 60m:0~+35mm

Total Height > 60m:0~+50mm

- 2. Hoistway walls shall be 200mm concrete walls.
- 3. Elevator hoistway is preferably not located in the space above accessible area. If the actual situation cannot meet the regulations, please contact us.
- 4. If elevator hoistway is of steel structure construction, please contact us.
- 5. Hoistway and machine room walls, floors and roofs should be able to absorb a large number of elevator operation noise.
- 6. Hoistway and machine room should not be located directly adjacent to bedrooms, classrooms, wards, library or any other places where low noise is required. Where such arrangements need to be imposed, the building contractors must be responsible for taking measures of sound insulation and cushioning.

#### Work to be done by Building Contractors:

- 1. The preparatory work for elevator installation outlined below should be undertaken by building contractors in accordance with Hitachi drawing and applicable national or local codes and regulation.
- 2. Prepare hoistway with proper framing and enclosure, suitable pit of proper depth with drains and water-proofing if required, properly lighted and ventilated machine room of adequate size with concrete floor, access door, ladder and guards as required.
- 3. Provide and/or cut all necessary holes, chases, and openings and finish after equipment installation.
- 4. Supply and secure all supports, reinforced concrete slabs, etc., necessary for installation of the machinery, doors, buffers, etc.
- 5. Furnish all necessary cement and/or concrete for grouting-in of brackets, bolts, machine beams etc.
- 6. Prepare and erect suitable scaffolding and protective measures for the works in progress.
- 7. Furnish main for three-phase electric power and single-phase lighting supply to hoistway, following the instructions of the elevator contractors on outlet position and wire size.
- 8. Provide, free of charge, a suitable theft-proof storage area for materials and tools during erection work.
- 9. Supply electric power for lighting of work area, installation work, elevator testing and spray painting.
- 10. Suspension hook in the machine room with required loading as shown in this catalogue.